

**From:** [Moore, Gary](#)  
**To:** [Powell, Greg](#)  
**Subject:** F.J. Doyle Salvage Site  
**Date:** Monday, October 01, 2018 10:46:40 AM

---

Greg:

Can you get this to the right person if not you?

We are going to be demolishing a building at a former PCB dismantling facility. They did do cutting and grinding on the transformers. It is a metal building with wood structures.

We are going to do the following: Asbestos Inspection – Required for Reno/Demo  
We are planning on doing PCB wipe samples to include analysis for Aroclor 1268 (Galbestos?)  
We are going to sample for lead paint

Question: Is there a need to include Dioxins/Furans for the wipe samples?

Thanks

**Gary W. Moore (6SF-ER)**  
**Federal On-Scene Coordinator**  
**U.S EPA Region 6**  
**1445 Ross Ave, Suite 1200**  
**Dallas, TX 75202-2733**  
**Cell: 214.789.1627**  
**[moore.gary@epa.gov](mailto:moore.gary@epa.gov)**